

# In-Ear Headphones Montblanc MTB 03

**MONTBLANC** 

## Quick Start Guide

Guide de démarrage rapide

Guía de inicio rápido

Kurzanleitung

Guida rapida



Guia de início rápido

Краткое руководство

빠른 시작 설명서

快速入门指南

快速入門指南






Montblanc  
Sound App



# 1. Charge

Chargement | Carga | Laden | Ricarica | A carga | Зарядка | 충전 | 充电 | 充電





## 2. Pair

Couplage | Conectar | Verbinden | Accoppiamento | Conectar | Подключить | 연결 |  
已连接 | 配對




### 3. Ear Tips

Embouts | Almohadillas | Ohrstöpsel | Tappo per le orecchie | Pontas de terra | Ушные вкладыши | 이어팁 | 耳塞 | 耳塞




## 4. Fit

Ajustement | Ajuste | Passform | Regolazione | Em forma | Настройка | 조정 | 定制 | 定制



## 5. Touch Control

Contrôle tactile | Control tactil | Berührungssteuerung | Controllo touch | Controle de toque | Сенсорное управление | 터치 컨트롤 | 触控式 | 觸控式



## 6. Status LED

LED des écouteurs | LED de auriculares | Kopfhörer-LED | LED delle cuffie | LED de fone de ouvido | Светодиод наушников | 헤드폰 LED | 耳机 LED | 耳機 LED



### Pairing mode

Mode de couplage  
Modo de emparejamiento Bluetooth  
Bluetooth-Kopplungsmodus  
Modalità di accoppiamento Bluetooth  
Modo de pareamento Bluetooth  
Режим сопряжения Bluetooth  
블루투스 페어링 모드  
藍牙配對模式  
藍牙配對模式



### Paired

Jumelé  
Conectado  
Verbunden  
Collegato  
Conectado  
Подключено  
연결됨  
连接的  
連接的



### Firmware update

Mise à jour du firmware  
Actualización de firmware  
Firmware-Update  
Aggiornamento del firmware  
Atualização de Firmware  
Обновление прошивки  
펌웨어 업데이트  
固件升級  
固件升級



### Reset

Réinitialisation  
Reiniciar  
Zurücksetzen  
Reset  
Reinicialização  
Сброс  
초기화  
重启  
重啟





### High

Batterie haute | Bateria alta | Hoher Batteriestatus | Batteria alta | Bateria alta | Высокий заряд  
батареи | 배터리 잔량 높음 | 电量高 | 電池電量高



### Medium

Batterie moyenne | Bateria media | Mittlerer Batteriestatus | Batteria media | Bateria média |  
Средний заряд батареи | 배터리 잔량 보통 | 电量中等 | 電池介質



### Low

Batterie faible | Bateria baja | Niedriger Batteriestatus | Batteria bassa | Bateria fraca | Низкий  
заряд батареи | 배터리 잔량 낮음 | 电量低 | 電量不足



### Empty

Batterie vide | Bateria agotada | Leere Batterie | Batteria scarica | Bateria descarregada |  
Разряженная батарея | 배터리 방전 | 无电量 | 空電池




### Error

Erreur de chargement | Error de carga | Ladefehler | Errore di carica | Erro de carregamento |  
Ошибка зарядки | 충전 오류 | 充电错误 | 充電錯誤

## 7. Reset

Réinitialisation | Reiniciar | Zurücksetzen | Reset | Reinicialização | C6poc | 초기화 | 重启 | 重启



[www.montblanc.com/smart-headphones](http://www.montblanc.com/smart-headphones)

Google Play and the Google Play logo are trademarks of Google LLC. Apple logo and App Store are trademarks of Apple Inc., registered in the U.S. and other countries. The Bluetooth® word mark and logos are registered trademarks owned by Bluetooth SIG, Inc. and any use of such marks by Montblanc-Simplo GmbH is under license. Other trademarks and trade names are those of their respective owners.

**Montblanc International Guarantee**

Your Montblanc product has been manufactured according to the high quality standards of Montblanc. This Montblanc product is covered by the Montblanc International Guarantee against defects in manufacturing and materials for a period of two years, according to the terms set forth in the Safety Manual.

---

**MODEL****DATE OF PURCHASE**

---

---

**IDENT no.****MONTBLANC AUTHORISED RETAILER**

---

---

**SERIAL no.**

---

# Guarantee Certificate

